# MAGIC VOICE USER'S GUIDE ERRATA SHEET

This information replaces certain sections in your Magic Voice User's Guide.

---

1. The following paragraph concerning the RDY command on page 15 will not work as described and should be ignored by the user:

   This command can also be used by BASIC programs to detect the presence of a speech module in a system. The variable named "RDY" will be zero when a program is LOADed and RUN if a speech module is not present. If the module is present the value of "RDY" will be -1.

   A correct way to detect the presence of MAGIC VOICE while using a BASIC program is as follows. A description of this method is found on page 21 for assembly language programmers.

```
10 IF PEEK(49176)<> 234 THEN GOTO 60:REM CHECK IF MODULE PRESENT
20 IF PEEK(49177)<> 234 THEN GOTO 60
30 IF PEEK(49178)<> 96 THEN GOTO 60
40 SAY1:SAY2:SAY3:REM PUT CODE THAT USES MODULE HERE
50 GOTO 50
60 PRINT"YOU FORGOT YOUR MAGIC VOICE":REM PUT "NO MODULE" CODE HERE
70 END
```

2. We greatly appreciate end-user feedback concerning our products and supporting documentation. Please forward your comments to:

   Documentation Support Group
   Software Division
   Commodore Business Machines, Inc.
   West Chester, PA 19380